

CF74

BMW F650 1997-/F650ST

MONTAGE SET			
ID	Popis	Kat. číslo	Ks
1	Steel bar 10x165x30x30	-	1
2	Dural. roller – 10mm	113	2
3	Washer M10	804	4
4	Cap nuts M10	961	2
5	Plastic plug-in tube	X32	2
6	Nuts imbus M10x120mm	881	1
7	Lock nut M10	810	1

Instructions:

- 1.) Attach both frames to the motorcycle and fix them at bottom part.
- 2.) Push the ID.1 steel rod through the frame and tighten it with M10 ID.4 nuts. Also use two ID.2 rollers(cylinders) and ID.3 washers.
- 3.) For the upper part, use the M10 ID.6 screw with M10 ID.3 washers and tighten with M10 ID.7 nut.
- 4.) Finally put the plastic plugs into the ID.5 pipe

