

CF90

Benelli TNT 125 2017-

Kit for left side			
ID	Description	Cat.no.	pcs
1	Frame	CF90	1
2	Bolt M8x80	843	2
3	Washer M8 flat	802	2
4	Bolt M10x130	883	1
5	Washer M10 flat	804	1
6	Plastic plug M10	X4	1
7	RDmoto sticker		1

Kit for right side			
ID	Description	Cat.no.	Pcs
1	Rám	CF90	1
2	Safety nut M8	809	2
3	Washer M8 flat	802	2
4	Washer M10 flat	804	1
5	Safety nut M8	810	1
6	Plastic plug M8	X5	2
7	RDmoto sticker		1

We recommend using a medium-strenght thread glue.

- 1.) Begin by dismantling the original plastic and the chain cover on left side, as well as disassembling the rear original screw.
- 2.) Insert the M10 ID.5 Bolt through M10 ID.6 washer, ID.1 frame and the motorcycle frame.
- 3.) Remove the two original bolts at the front part of the bike (as shown on photo), then fit the M8 ID.3 washer onto M8 ID.2 bolt and push through crash frame and the motorcycle frame.
- 4.) On the right side, attach the second part of ID.1 crash farme onto protruding ID.5 and ID.2 bolts, then attach the M10 ID.5 and M8 ID.3 washers plus M10 ID.6 and M8 ID.2 nuts.
- 5.) Tighten the whole assembly now.
- 6.) We recommend mounting screws on the left side first for easier oil filter change.



